

## 80-8 MAXIAL TOP STOP INSTALLATION INSTRUCTIONS

- *The Maxial Top stop has been redesigned and the installation method has changed.*
- *Top stop installs from the side of the track which makes contact with scaffolding.*

Step 1: Hold the top stop as shown in figure 1.



*Figure 1*

Step 2: Rotate into position with “EARS” inside track as shown in figures 2 and 3



*Figure 2*



*Figure 3*

Step 3: Flip down into position as shown in figure 4 and 5



Figure 4



Figure 5

Step 4: Make sure safety catch is securely engaged To the inside of channel track.  
(See figure 6)



Figure 6

Installed top stop photo from back side of track

